

Delaware Department of Transportation
QUESTIONS AND ANSWERS
DOT2009-HERB_APP
HERBICIDE APPLICATION
Thursday, November 19, 2020

Q #	Question	Answer
9	Will pre-emergent be applied with the bare ground mix or a separate application?	Pre-emergent is to be applied with the bare ground mix.
8	There are no quantities given for pre-emergent. Should this be calculated at the same quantities as guide rail and island spraying.	Correct, calculate at the same guardrail and island spraying.
7	For the application on the islands, how are the acres measured? Gallons used converted to acres? Assuming this is crack and crevice work. Is that correct?	The total acreage for each County is a pre-determined quantity that is based on our current road inventory, not Gallons applied. Our preference is to have the application applied directly to the cracks and crevices. However, in some instances, broadcast applications can be made at the discretion of the applicator.
6	Is the guide rail lane mile considered a sprayed area mile or travel mile? We would usually assume about 20% of travel miles would be sprayed.	The guard rail lane mile is considered the spray area mile; not travel mile.
5	Guide rail pattern width?	Three feet in front of guard rail and one foot behind guard rail.
4	Is the brush lane mile considered a sprayed area mile or travel mile? We would usually assume about 60% of travel miles would be	The brush lane mile is considered the spray area mile; not travel mile.
3	Guide rail pattern width?	Three feet in front of guard rail and one foot behind guard rail.
2	What is the required height for brush spraying?	Fourteen Feet
1	Is there additional technical scope information available?	No